

Manual Load Weight Fillers

Model # 32100

How It Works

Product is conveyed into the hopper and drops through to the container. There is a two stage throttle hopper which meters final product into the container, meeting exact weight requirements

Features

- Fills containers by weight up to 70 lbs
- Manually load and unload boxes from the scale
- Drop through filling style



Model # 33050

How It Works

Product is conveyed into the initial filling hopper. Product is released and flows across the transfer tray and through the secondary hopper into the containers below. As the weight approaches the final fill weight the metering feed slows down for accurate filling every time.

Features

- Fills up to 5,000 lbs per hour
- Gentle filling for fragile products
- "No Box - No Fill" technology
- Belt or vibratory transfer tray

